## **Installation Steps**



1 Use a level to mark the screw holes on the wall and drill the holes.



2 Install the screw anchors, tighten the screws with a screwdriver, and secure the bracket.



Neatly wrap the cables around the bracket.



Connect the reserved cables to the router and the device to complete the setup.