

PCI-E WiFi Card

USER MANUAL


WiFi 6/6E

We're so glad you've purchased our Bluetooth PCIe WiFi Card, please install the the adapter driver and Bluetooth driver before using. The installing instruction as below.

1. How to install the AX210 card driver?

01. Scan the QR code to download the driver program.


02. The downloaded file is a compressed file and needs to be decompressed. Select the corresponding system driver to install. as the picture shows:




03. Click driver for Win10 64bit for next step.




1



2





3




4


2. How to connect the PCI-E card to Wi-Fi?

01. Open the Internet icon  at the lower right corner of the computer.
02. Searching and connecting the Wi-Fi you preferred on the detected Wi-Fi list.
03. Enter the Wi-Fi password to connect.





04. Finally you are connected to the Wi-Fi.



3. How to install the Bluetooth driver?

01. Select proper driver to install.



BT-22.200.0-32-64UWD-Win10-Win11.exe





WiFi-22.160.0-Driver32-Win10.exe




WiFi-22.200.0-Driver64-Win10-Win11.exe


02. Double click the file to running, and click the “Next” button twice.




03. Please accept the terms of the agreement, then click the “Next” button.




04. Please click “Install”.



05. The following process bar of Bluetooth driver installation will show up.



06. Click the "Finish" button when the Bluetooth driver can install successfully.




4. How to connect the Bluetooth Earphones with the adapter?

01. Find the Bluetooth icon  in the lower right corner of the desktop.

02. Right-click the mouse, select the “Add Device”, searching the Bluetooth.

03. Make sure your Bluetooth device was turned on and ready to pair.



04. Bluetooth earphone will be detected below after a while.
Double click the earphone icon to pairing.

Bluetooth & other devices



Add Bluetooth or other device

Add a device



Add a device

Choose the kind of device you want to add.



Bluetooth

Mice, keyboards, pens, or audio and other kinds of Bluetooth devices



Wireless display or dock

Wireless monitors, TVs, or PCs that use Miracast, or wireless docks



Everything else

Xbox controllers with Wireless Adapter, DLNA, and more

Add a device



Add a device

Make sure your device is turned on and discoverable. Select a device below to connect.



EWA Audio A150

Add a device



Your device is ready to go!



EWA Audio A150