

70mm

快速安装指南
WIFI 6 AX1800 USB 无线网卡

8832BU

驱动下载二维码:



驱动下载网址:
<http://www.edup.cn/ep-ax1696/>

一、扫描二维码或将网址输入到浏览器下载驱动程序。

EP-AX1696 驱动
支持 Win 11/10
[点击下载](#)

二、下载后的文件为压缩文件，需要将其解压。然后选择相应的系统驱动程序进行安装。如图所示:



三、驱动程序安装进程中，请等待大约一分钟:



四、安装进程完成后，请选择“否，稍后再重新启动计算机”，然后点击“完成”。

五、在完成上面的四个步骤后，网卡就可以正常使用，请正确操作网卡去连接wifi上网:



01. 点击电脑右下角此图标，打开去搜索WiFi信号，在列表中选择自己需要连接的WiFi 信号，图中以“CESHI-5G”信号为例:



02. 输入“CESHI-5G”的密码:



03. 当连接上WiFi成功的状态:




78mm

Quick Installation Guide
WIFI 6 AX1800 USB Wireless Adapter

8832BU

Driver download QR code:




Driver download URL:
<https://www.szedup.com/support/driver-download/usb-adpeter/ep-ax1696/>


1. Scan the QR code or enter the URL into the browser to download the driver.

EP-AX1696 Driver (RTL8832BU)
For Win11/10 64-bit [Download](#) For Linux [Download](#)

2. The downloaded file is a compressed file and needs to be decompressed. Select the corresponding system driver to install, as the picture shows:




3. It may take about 1 minute to complete installation, wait for the




4. Choose "No, I will restart my computer later" to finish the process.

5. Connect wifh correctly then you can access to the Internet.



01. Open the Internet icon at the lower right corner of the computer.
02. Searching and connecting the Wi-Fi you preferred on the detected Wi-Fi list.
03. Enter the Wi-Fi password to connect.



04. Finally you are connected to the Wi-Fi.

