



User Guide

Wi-Fi 7 Bluetooth PCIe Adapter

1. How to install the card driver?

01. Scan the QR code to download the driver.

02. The downloaded file is a compressed file and needs to be decompressed. Select the corresponding system driver to install, as the picture shows:








MediaTek_Bluetooth
_MT7927-MT7925
_Installer_Corrected



MediaTek_WiFi_
MT7927-MT7925_
Installer_Corrected.exe


03. Double click the driver program for installation.







2. How to connect the card to Wi-Fi ?

01. Open the Internet icon  at the lower right corner of the computer.
02. Searching and connecting the Wi-Fi you preferred on the detected Wi-Fi list.
03. Enter the Wi-Fi password to connect.





04. Finally you are connected to the Wi-Fi.



3. How to install the Bluetooth driver?

01. Select proper driver to install.








MediaTek_Bluetooth
_MT7927-MT7925
_Installer_Corrected



MediaTek_WiFi_
MT7927-MT7925_
Installer_Corrected.exe

02. Double click the file to running, and click the "Next" button twice.





4. How to connect the Bluetooth Earphones with the adapter?

01. Find the Bluetooth icon  in the lower right corner of the desktop.
02. Right-click the mouse, select the "Add Device", searching the Bluetooth.
03. Make sure your Bluetooth device was turned on and ready to pair.

Add a Bluetooth Device

Allow a Device to Connect

Show Bluetooth Devices

Send a File

Receive a File

Join a Personal Area Network

Open Settings

Remove Icon

04. Bluetooth earphone will be detected below after a while.
Double click the earphone icon to pairing.

Bluetooth & other devices



Add Bluetooth or other device

Add a device



Add a device

Choose the kind of device you want to add.



Bluetooth

Mice, keyboards, pens, or audio and other kinds of Bluetooth devices



Wireless display or dock

Wireless monitors, TVs, or PCs that use Miracast, or wireless docks



Everything else

Xbox controllers with Wireless Adapter, DLNA, and more

