




CAUTION: UTILIZING INCORRECT CABLES OR POE INJECTORS MAY RESULT IN IRREVERSIBLE DAMAGE TO EQUIPMENT



Note: Items 1 and 2 refer to two different installation and usage modes.

Easy installation

- Insert the Ethernet cable through the plastic ring.
- Place the silicone sealing ring onto the cable, ensuring it tightly wraps around the cable.
- Insert the silicone sealing ring along with the cable into the connector housing.
- Install the silicone seal ring onto the base of the RJ45 socket housing interface.
- Insert the RJ45 cable into the interface until you hear a click.
- Tighten the waterproof seal onto the housing to ensure the connection is secure.
- Secure the RJ45 cable to the connector by tightening the plastic ring.
- Ensure the connection is fully established and secured.