


Installation Guide

WiFi 6 AX1800 USB Wireless Adapter

[Free Drive](#)

1. Connect to a Computer



2. Driver Installation (Windows 10)

1. Insert the network adapter into a USB port on your computer.
2. Open the **File Explorer** and navigate to the **WiFi6 Adapter** (created by the device).



CD Drive(H:) Wi-Fi6 Adapter

0 bytes free of 1.91 MB

CDFS

3. Double-click **auto_load.exe** to begin the installation.




auto_load.exe



autorun.inf

4. Wait for the installation to complete.



5. After the installation is complete, the window will automatically close. Restart your computer, and you can now connect to Wi-Fi from the lower-right corner of your desktop.



Windows 7 Feature Limitation Notice:

Due to system and hardware protocol restrictions, only the USB 2.0 interface protocol is available under the Windows 7 operating system, and the wireless hotspot (AP) feature cannot be enabled. If you need to use the USB 3.0 protocol, it is recommended to upgrade to Windows 10 or a later version of the operating system.

3. Frequently Asked Questions (FAQ)

Network Connection Problems

1. Slow or Unstable Internet

- Check that your network is on the **5GHz** band for better speed and reliability.
- Avoid placing the network adapter near walls or sources of magnetic interference.
- Try using a different USB port, especially one further from interference sources.

2. Adjust Router Settings

- Access your router's settings by entering 192.168.1.1 or 192.168.0.1 into your browser.
- In the router's admin page, adjust the channel and bandwidth settings to reduce interference. Choose less congested channels if possible.
- If the above troubleshooting steps don't resolve the issue, please contact our technical support for further assistance.